



Turn signals & hazard warning lamp 1



Turn singnals & hazard warning lamp 2



Harness connector	Name	Page
CA01	To instrument harness connector 1	29
CA03	To instrument harness connector 3	29
CA12	FL combination headlamp harness connector	28
CA18	FR combination headlamp harness connector	28
DR01	To instrument panel harness connector 1	60
DR08	Left exterior rearview mirror connector	60
DR18	Right exterior rearview mirror connector	62
DR19	FR door to Instrument panel harness connector1	62
IP07	Hazard warning switch connector	42
IP13	To FR door harness connector	41
IP32	Body harness connector 1	41
IP36	To engine compartment harness connector 2	41
IP38	To FL door harness connector	41
IP42	Light combination switch harness connector	42
IP62	BCM harness connector 2	42
IP63	BCM harness connector 3	41
IP65	BCM harness connector 5	42
IP79	Hazard flasher relay harness connector	
SO09	To instrument panel harness connector 2	52
SO24	RR combination lamp harness connector	52
SO31	RL combination lamp harness connector	52
G2	Engine compartment grounding	69
G4	Engine compartment grounding	69
G6	Instrument panel grounding	72
G10	Instrument panel grounding	72
G13	Body harness grounding	73
G14	Body harness grounding	73